


## 42-0516 Removal and Install. of release knob for parking brake hand lever

Operation no. of operation texts and work units or standard texts  
and flat rates  
42-5871

### Model 201



P42-5017-55

|  |  |
|--|--|
| Release knob (a) .....                       | pull off with pliers.                        |
| Star-shaped part (b) .....                   | cut open at side and remove from lever (75). |
| Plastic residues (arrow) .....               | remove from release rod, if present.         |
| New release knob with star-shaped part ..... | press on with plastic wedge.                 |