


72-210 Removal and installation of door holder

Special tool



Removal, intallation

- 1 Remove door lining (72-100).
- 2 Loosen plastic foil in lower range.
- 3 Remove rubber sealing frame. Remove lock on bolt. Remove bolt with special tool and take off spacing washer.
- 4 Remove screws on door inside plate.
- 5 Remove door holder.
- 6 For installation proceed vice versa.

